

NAME

etherswitch - Ethernet switch framework

SYNOPSIS

To compile the framework into the kernel, place the following lines in the kernel configuration file:

```
device etherswitch  
device miiproxy  
device iicbus
```

DESCRIPTION

The **etherswitch** driver provides a framework for Ethernet switch devices.

FILES

/dev/etherswitch? **etherswitch** device nodes

SEE ALSO

arswitch(4), iicbus(4), ip17x(4), rtl8366rb(4), e6060sw(4), adm6996fc(4), ksz8995ma(4), ukswitch(4), etherswitchcfg(8)

HISTORY

The **etherswitch** framework first appeared in FreeBSD 10.0.

AUTHORS

Stefan Bethke