

**NAME**

**snd\_cmi** - CMedia CMI8338/CMI8738 PCI bridge device driver

**SYNOPSIS**

To compile this driver into the kernel, place the following lines in your kernel configuration file:

```
device sound  
device snd_cmi
```

Alternatively, to load the driver as a module at boot time, place the following line in loader.conf(5):

```
snd_cmi_load="YES"
```

**DESCRIPTION**

The **snd\_cmi** bridge driver allows the generic audio driver sound(4) to attach to the CMedia CMI8338/CMI8738 audio cards.

**HARDWARE**

The **snd\_cmi** driver supports the following sound cards:

- ⊕ CMedia CMI8338A
- ⊕ CMedia CMI8338B
- ⊕ CMedia CMI8738
- ⊕ CMedia CMI8738B

**SEE ALSO**

sound(4)

**HISTORY**

The **snd\_cmi** device driver first appeared in FreeBSD 4.3.

**AUTHORS**

Orion Hodson <*O.Hodson@cs.ucl.ac.uk*>