

NAME

ucycom - device driver for Cypress CY7C63743 and CY7C64013 USB to RS232 bridges

SYNOPSIS

To compile this driver into the kernel, place the following line in your kernel configuration file:

```
device usb
device hid
device ucom
device ucycom
```

Alternatively, to load the driver as a module at boot time, place the following line in loader.conf(5):

```
ucycom_load="YES"
```

DESCRIPTION

The **ucycom** driver provides support for the Cypress CY7C63743 and CY7C64013 bridge chips. These chips were designed to provide a low-cost transition path to USB for existing RS232 devices, and have fairly limited capabilities.

The **ucycom** driver behaves like a tty(4).

HARDWARE

The **ucycom** driver currently supports the following devices which incorporate Cypress USB to RS232 bridge chips:

- DeLorme Earthmate USB GPS receiver

FILES

```
/dev/ttyU*    for callin ports
/dev/ttyU*.init
/dev/ttyU*.lock
                corresponding callin initial-state and lock-state devices
```

```
/dev/cuaU*    for callout ports
/dev/cuaU*.init
/dev/cuaU*.lock
                corresponding callout initial-state and lock-state devices
```

SEE ALSO

tty(4), ucom(4), usb(4)

HISTORY

The **ucycom** driver first appeared in FreeBSD 5.3.

AUTHORS

The **ucycom** driver and this manual page were written by Dag-Erling Smórgrav <*des@FreeBSD.org*>.